

Summary – compilation of (pseudo) instructions

0x020	
0x021	
0x022	
0x023	
0x024	
0x025	
0x026	
0x027	
0x028	
0x029	
0x02A	
0x02B	
0x02C	
0x02D	
0x02E	
0x02F	

```
TABLE: .byte    3, 5, 1, 2

BUF:    .word   0x01020304

A:      .byte   0x15

        .align

_START: mov     r0, #128
```


ASSEMBLER

Location counter

0x020

Labels Table

Summary – compilation of (pseudo) instructions



ASSEMBLER

Location counter

0x030

Labels Table

TABLE	0x020
BUF	0x024
A	0x028
_START	0x02C

Load/store instructions – addressing modes

1. Indirect addressing – base addressing with no offset


Access to operand in two steps :

a) Variable's address is loaded into a base register with:

```
adr r1, stev1
```

b) Then we use load/store instruction to access memory location on address stored in base register:

```
ldr r0, [r1]    @ r0 <- mem32[r1]
str r5, [r0]    @ mem32[r0] <- r5
```



Remark:

adr is not real instruction. Assembler replaces it with ALU instruction, that calculates address with R15 (PC) and constant.

Primer:

adr r0, stev1 assembler replaces with eg. **sub r0, pc, #2c**
(ALU instructions that puts real address into r0)

Load/store instructions – addressing modes

Examples for base indirect addressing mode without offset :

32-bit operands

```
adr r1, VAR1           @ r1 <- addr of var. VAR1
ldr r0, [r1]           @ r0 <- mem32[r1]
str r0, [r1]           @ mem32[r1] <- r0
```

16-bit operands

```
adr r1, VAR2           @ r1 <- addr of var. VAR2
ldr(s)h r0, [r1]       @ r0 <- mem16[r1]
strh r0, [r1]          @ mem16[r1] <- r0[b0..b15]
```

8-bit operands

```
adr r1, VAR3           @ r1 <- addr of var. VAR3
ldr(s)b r0, [r1]       @ r0 <- mem8[r1]
strb r0, [r1]          @ mem8[r1] <- r0[b0..b7]
```

s .. operand is signed number !!!

Load/store instructions – addressing modes

2. Indirect addressing – base addressing with immediate offset

(preindex with immediate offset):

```
ldr r0,[r1, #n12]      @ r0<-mem32[r1+n12]
str r0,[r1, #n12]     @ mem32[r1+n12]<-r0
strb r0,[r1, #n12]    @ mem8[r1+n12]<-r0[b0..b7]
```


```
ldr(s)b r0,[r1, #n8]   @ r0<-mem8[r1+n8]
ldr(s)h r0,[r1, #n8]  @ r0<-mem16[r1+n8]
strh r0,[r1, #n8]     @ mem16[r1+n8]<-r0[b0..b15]
```

n12 – 12-bit signed offset

n8 – 8-bit signed offset

Examples:

```
ldr r0, [r1, #4]      @ r0 <- mem32[r1 + 4]
ldr r5, [r0, #-20]    @ r5 <- mem32[r0 - 20]
                        @ r0 must contain proper address!!!
strb r7, [r2,#10]     @ mem8[r2 + 10] <- r7[b0..b7]
                        @ r2 must contain proper address!!!
```




Final address is a sum of values : **base register** and **signed offset**

Arithmetic-logic instructions

3. Immediate addressing

`mov r0, #100` @ `r0 <- 100`
`add r2, r7, #0x20` @ `r2 <- r7 + 32`
`sub r5, r5, #1` @ `r5 <- r5 - 1`



$$\text{Immediate operand} = (0..255) * 2^{2*(0..12)}$$

32-bit immediate operand is a 8-bit number, that can be shifted for even number of places inside 32 bit content. A value of immediate operand cannot be arbitrary! It's determined by assembler – if it's not possible then we get warning from assembler.

Immediate operand is a part of instruction, therefore it must be known before compilation from assembly to machine language. Immediate operands are **constants**.

Arithmetic-logic instructions (immediate addressing)

Examples

Valid immediate operands:

```
mov r1,#255          @ r1 <- 0b00000000000000000000000001111111
add r2,r2,#1024      @ r2 <- r2 + 0b00000000000000000000000100000000
sub r1,r0,#110592    @ r1 <- r0 - 0b00000000000000000110110000000000
```

Invalid immediate operands :

```
mov r1, #257        @ r1 <- 0b00000000000000000000000100000001
add r7, r3, #65535  r7 <- r3 + 0b00000000000000001111111111111111
```

Immediate operand is **unsigned 8-bit number**, that can be shifted for $2 \cdot n$ bits on left (where n can be between 0 and 12).

Arithmetic-logic instructions

4. Direct register addressing

- Purpose: for calculation from register content and movement of the content between registers.

```
add r2, r7, r12
sub r4, r5, r1
mov r1, r4
```

Arithmetic-logic instructions, list

- **Arithmetic instructions:**

```
add r0, r1, r2    @ r0 <- r1 + r2
adc r0, r1, r2    @ r0 <- r1 + r2 + C      (add with C)
sub r0, r1, r2    @ r0 <- r1 - r2
sbc r0, r1, r2    @ r0 <- r1 - r2 + C - 1  (-not(C)=- (1-C)= C-1
rsb r0, r1, r2    @ r0 <- r2 - r1          (reverse subtract)
rsc r0, r1, r2    @ r0 <- r2 - r1 + C - 1  (rev. sub -not(C) )
```

- **Logic instructions:**

```
and r0, r1, r2    @ r0 <- r1 AND r2
orr r0, r1, r2    @ r0 <- r1 OR r2
eor r0, r1, r2    @ r0 <- r1 XOR r2
bic r0, r1, r2    @ r0 <- r1 AND NOT r2
```

- **Move register's content:**

```
mov r0, r2        @ r0 <- r2
mvn r0, r2        @ r0 <- NOT r2
```

- **Comparisons:**

```
cmp r1, r2        @ set CPSR flags on r1 - r2
cmn r1, r2        @ set CPSR flags on r1 + r2
tst r1, r2        @ set CPSR flags on r1 AND r2
teq r1, r2        @ set CPSR flags on r1 XOR r2      (equivalence test)
```